



Type Z10

A purlin clip designed to suit a large range of purlin sections. Can be used with the Type SW for use on inclined purlins (see page 55).




Material: Mild steel, zinc plated.

Code	Purlins	Rod	Safe Working Load (FOS 3:1)	Tightening Torque
			Tensile kN	Nm
Z10	Kingspan Multibeam 2 and 3	M10	0.2	8
Z10	Metsec	M10	0.1 - 0.2	8
Z10	Zeta	M10	0.15	8



How to install...



➔ Safe working loads are subject to the strength of the purlin. Please refer to the purlin manufacturer's literature.


Type WF

The Webfix allows a quick installation directly from the web of purlins.




Hole Position: Canted Purlins

When purlins are connected to a sloping roof beam, the maximum allowable distance X (hole centre to the bottom edge of the purlin) must decrease.



Hole Position: Inclined Purlins

Type WF adjusts to whatever angle is required. Hole position is not a limiting factor on product installation.



Material: Mild steel, zinc plated.

Code	Rod	Safe Working Load (FOS 5:1)	Maximum Purlin Thickness	Hole Ø	Maximum Distance X at Angle of		
		Tensile kN			10°	20°	30°
WF10	M10	1.0	4	18	103	94	74



How to install...

- 1) Squeeze the legs of the Type WF together and push through the hole until it clicks into place.
- 2) Assemble with the nut, ensuring full thread capture.

